

Do some of your tanks lack automatic level monitoring, but you still want to be able to read the volumes in SiteInfo? Then, SiteBasic is the right choice.

SiteBasic, or manual level monitoring, as we call them, is the tool for those clients, who do not need automatic level monitoring. The tool can be used by providers in any easy way to get information from their clients, when it is time to deliver.

You save money as you do not need to invest in a automatic level monitoring equipment, installation in drum or a tank. When using hand measuring, you simply enter the measured level data in our web app by scanning the QR-code in your smartphone's QR-reader.



How do I get started?

- The installation is set up on SiteInfo and MCD provides you with the QR instruction plate.
- You provide access to SiteInfo for your client, in order to manually feed the measuring level.
- Inform the client that he has access to SiteInfo by the web app.
- The QR instruction plate is placed at the tank. Is the plate is to be scanned by a smartphone, it should be placed outside a non-explosive proofed area, when needed.
- Your customer reads the product level, then scanning the QR-kod and enters the level in the web app on his smartphone.
- In SiteInfo, you assign your customer permission to enter manual measuring value, and informs the customer that he now has access to the function.



Now, you got started!

TECHNICAL SPECIFICATION

Connectivity:	Mobile phone with QR-reader
Material:	Eloxerated aluminium with UV-resistant label
Accessories:	U bolt for assembly on 2" pipes
Dimension:	185 x 135 x 3 mm
Protection:	IP 68

WELCOME TO PLACE YOUR ORDER

+46 (0)155-22 27 90 @ order@mcd.se www.mcd.se